

Pro-GHVFD



Variable speed automation for sectional and rolling doors

Instructions and warnings for installation and use

Nice

Contents

Warranty	3
Verification of Operator and Hardware	4
PRO-GH & PRO-GHC Specifications	5
Important Safety Instructions	6
Important Installation Instructions	6
Installation Instructions	7
Electrical Connections	10
SECTION A: PRO-GHV: PRO-GHCV Full Feature Logic Board Smart 10.0	11
Connection of External Single-Button Device	13
Modes of Operation	13
Programming Instructions	15
Run-Timer Setup	15
Mid-Stop Setup	16
Timer to Close Setup	16
Delay on Close Setup (only for use with optional apartment board)	16
On-Board Receiver Programming	16
Installing the Antenna	16
Programming the On-Board Radio Receiver	17
Operation	17
To Erase all Learned Transmitters	17
Replacing Remote Control Batteries	17
Dip-Switch Setup	18
SECTION B: For all Operator Control Types	19
Limit Switch Adjustment	19
SECTION C: For Operators with Interface Modules or Logic boards	20
Installation of Nice N-1 or N-4 Photocells	20
Installation Safety Precautions	20
Wall installations	20
NICE N-4 Photocell (MK00650)	21
Wall installation	21
For Nice Nema-1 and Nema-4 photobeams	22
FRABA N-4/4 Thru-Beam Photocell (MK00697)	23
Clutch Adjustment	24
In-Line Clutch	24
Fire Release Mechanism Installation	25
Brake Adjustment	26
Emergency Manual Operation	27
Operator Maintenance	28
Jackshaft Operator Pro-GH Parts Diagram	29
Jackshaft Operator Pro-GH Parts List	30
Jackshaft Operator Pro-GHC Parts Diagram	32
Jackshaft Operator Pro-GHC Parts List	33
MS100-WW-F 1-Phase Wiring Diagram	35
MS100-IM-WW-F 1-Phase Wiring Diagram	36
Notes	37

Warranty

Nice North America warrants that materials and workmanship are free from defects for a period of four (4) years or 100,000 cycles, whichever comes first. The start of the warranty will be determined by the date of invoice. Materials returned to Nice deemed defective after examination will be returned at the option of Nice with repaired, new, or re-manufactured parts.

Nice North America will not be responsible for any charges incurred in the process of returning defective material. All returned material must be received pre-paid, or it will not be accepted.

This warranty is limited, and in lieu of all other warranties expressed or implied. There is no expressed liability due on the part of the seller.

MP00046	#60, #80 Drive Chain and Sprockets
MP00024	Chain Spreader 1" - 1"
MP00025	Chain Spreader 1" - 1-1/4"
PRO-_W	Waterproof Modification
PRO-_4X	Corrosion Proof Modification
PRO-_X	Explosion Proof Modification
MP00007*	115 Volt Control Circuit
MP00061**	1.5 Sec Time Delay on Reverse
MP00001**	Timer to Close
PRO-PL	Separate Control Panel
MP00038	Fire Release Mechanism
MP00028	Hand Crank
9999999	Pusher Springs
MP00069-74	Auxiliary Trolley C/W Track & #41 Chain
MP00012-118	Dual Auxiliary Trolley C/W Track & #41 Chain
MX00001	Floor Level Disconnect in Lieu of Chain Keeper
MW00050,52	In-Line Torque Clutch

* Not available for logic board controls

** Standard feature with logic board controls

WARNING











DO NOT CONNECT TO ELECTRICAL POWER DURING
INSTALLATION OR SERVICING OF OPERATOR.

IMPORTANT

FOR ANY QUESTIONS CONCERNING THE SAFETY OR OPERATION OF THIS OPERATOR,
PLEASE CONTACT NICE AT 1-877-888-1116. **SAVE THESE INSTRUCTIONS.**

Verification of Operator and Hardware


Upon delivery of your Nice heavy-duty gearhead jackshaft door operator, please inspect the unit carefully for damage. Verify that operator horsepower, voltage, phase and amperage correspond to available power supply and door application. Check that along with your operator you have received the following standard hardware.

<p>1 x OPEN/CLOSE/STOP 3-Button Control Station</p>	
<p>1 x #50 Drive chain package: 4' (1.2m) c/w #50 connecting link</p>	
<p>1 x Drive Sprocket 50B12 or 50B15 c/w 2 set screws and keyway</p>	
<p>1 x Door Sprocket: 50B23 x 1" or 1-1/4" bore, 2 set screws and 1/4" x 1-1/4" keyway for sectional doors or 50B40 x 1" or 1-1/4" bore, 2 set screws and 1/4" x 1-1/4" keyway for rolling doors NOTE: Sprocket size and bore may vary according to door size and type, shaft size and drum diameter.</p>	
<p>1 x Chain Keeper</p>	
<p>1 x Keyring</p>	
<p>4 x 3/8" bolt, hex nut, lock washer and flat washer</p>	
<p>1 x pocket wheel hand chain 2 x door height less 4' (1.2m)</p>	
<p>1 x Warning Sign</p>	
<p>1 set of Fraba photocells</p>	

PRO-GH & PRO-GHC Specifications

PRO-GH and PRO-GHC heavy-duty jackshaft operators are designed for large commercial and industrial doors provided that doors are driven by a drive shaft. Model PRO-GH is essentially the same as model PRO-GHC with the exception that the PRO-GHC operator has a reinforced frame and pillow block bearings on reducer drive shaft.

Standard Operator Weight	PRO-GH (100-120 lbs) / PRO-GHC (120-150 lbs)		
Motor	Continuous duty 1725 RPM industrial type motor. Full overload protection.		
• Horsepower Range: PRO-GH	1/2 HP, 3/4HP, 1HP, 1.5HP (3-phase & 1-phase) / 2HP, 3HP, 5HP (3-phase only)		
• Horsepower Range: PRO-GHC	1/2 HP, 3/4HP, 1HP, 1.5HP (3-phase & 1-phase) / 2HP, 3HP (3-phase only)		
• Voltage	115V 1-phase (60Hz)	208V 3-phase (60Hz)	220V 1-phase (50Hz)
	208V 1-phase (60Hz)	230V 3-phase (60Hz)	380V 3-phase (50Hz)
	230V 1-phase (60Hz)	460V 3-phase (60Hz)	
		575V 3-phase (60Hz)	
Reduction	Primary: Heavy duty worm gear reducer 40:1 -44:1 reduction		
	Secondary: #50 chain and sprockets from operator to door shaft		
Output Shaft Speed	40-43 RPM		
Brake	Solenoid actuated drum and brake shoe braking system to prevent coasting and maintain door position.		
Wiring Type (3 Options)	Option 1: Full Feature logic board Smart 10.0 (UL325 (2010) compliant). NOTE: Nice compatible primary entrapment device must be connected for B2, T or TS (momentary or timer activation on close) feature.		
	Option 2: Relay logic controls with Interface Module (UL325 (2010) compliant). C2 Standard factory wiring (constant pressure on close, momentary contact on open and stop). If momentary contact on close (B2) wiring is desired, move "white" wire from terminal #6 to terminal #3. NOTE: Nice compatible primary entrapment device must be connected for B2 (momentary activation on close) or for T (timer to close) feature.		
	Option 3: Standard relay logic controls (not UL325 (2010) compliant, not available in US) C-2 Wiring constant pressure on close, momentary contact on open and stop. NOTE: If momentary contact on close (B2) wiring is desired, move "white" wire from terminal #5 to terminal #3.		
Transformer	24VAC control circuit, supplies power to drive control relays with 15VA power available for external devices.		
Limit Adjustment	4 micro switches that control door travel. These limit switches are activated by fully adjustable screw type cams.		
Emergency Disconnect	Floor level cable disconnect system with electrical cut-out feature allows person to manually operate door by chain hoist in case of emergency.		
Operator Dimensions:			



Important Safety Instructions

WARNING: To reduce the risk of injury or death:

- READ AND FOLLOW ALL INSTRUCTIONS
- Never allow children to operate or play with door controls. Keep the remote control (where provided) away from children.
- Personnel should keep away from a door in motion and keep the moving door in sight until it is completely closed or opened. **NO ONE SHOULD CROSS THE PATH OF A MOVING DOOR.**
- Test the door's safety features at least once a month. After adjusting the limit of travel, retest the door operator's safety features. Failure to adjust the operator properly may cause severe injury or death.
- For products having a manual release, if possible, use the manual release only when the door is closed. Use caution when using this release when the door is open. Weak or broken springs may cause the door to fall rapidly, causing severe injury or death.
- **KEEP DOORS PROPERLY OPERATING AND BALANCED.** See Door Manufacturer's Owner's Manual. An improperly operating or balanced door could cause severe injury or death. Have trained door systems technician make repairs to cables, spring assemblies, and other hardware.
- Press the "OPEN" device or use emergency disconnect mechanism if a person is trapped under the door.
- **SAVE THESE INSTRUCTIONS.** The owner or users must understand the safety and operation of door system. Insure that this installation manual be located close to the door system.

Important Installation Instructions

- READ AND FOLLOW ALL INSTALLATION INSTRUCTIONS
- Commercial door operators are never to be installed on a residential installation
- Install only on a properly operating and balanced door. A door that is operating improperly could cause severe injury. Have qualified service personnel make repairs to cables, spring assemblies, and other hardware before installing the operator.
- Remove all pull ropes and remove, or make inoperative, all locks (unless mechanically and/or electrically interlocked to the power unit) that are connected to the door before installing the operator.
- Install the door operator at least 8 feet or more above the floor if the operator has exposed moving parts.
- Do not connect the operator to the source of power until instructed to do so.
- Locate the control station: (a) within sight of the door, (b) at a minimum height of 5 feet so that small children cannot reach it, and (c) away from all moving parts of the door.
- Install the Entrapment Warning Placard next to the control station in a prominent location.
- For products having a manual release, instruct the end user on the operation of the manual release.
- Install non-contact entrapment protection devices (photocells) and/or contact entrapment protection devices (reversing edges). **NOTE:** photocells should be installed at no more than 6" from the floor. Edges should be installed on the leading edge of the door.


Installation Instructions

⚠ WARNING ⚠


DO NOT INSTALL THIS OPERATOR BEFORE READING THIS MANUAL CAREFULLY.

NOTE:


- Installation of operator must be done by a qualified installer. Door must be properly installed and working smoothly. Remove all door locks prior to installation.
- The PRO-GH, PRO-GHC operators have dual output shafts and may be mounted on right (standard) or left hand side of door. If handing of operator must be reversed, loosen set screws, remove drive sprocket and keyway and install on opposite side of drive shaft





For both the PRO-GH and PRO-GHC operators the handing of the operator should be stated at time of order. Depending on installation, if handing of chain hoist is not correct the hand chain may hang in door opening. If this is the case, swing chain off to the side and hook it over the top of the door jamb. If desired, the pocket wheel, chain guard and hand chain may be removed on site and installed on opposite side of universal disconnect shaft as shown below.





1. Install control station away from all moving door parts, within sight of the door and a minimum of 5 ft (1.5 m) from the ground.
2. Install entrapment warning sign next to control station.



3. As a general rule, the door operator should be installed below the drive shaft and as close to the door as possible. The ideal distance between the operator drive shaft and the door shaft is approximately 12" (30cm) to 15" (38cm). The operator may be wall/bench mounted or bracket /shelf mounted. These two mounting configurations are shown below:




4. Mount the operator to the wall, hood or bench with 3/8" bolts, nuts and washers provided or with lag bolts and shields if installation requires it. Make sure that operator is secured but do not tighten bolts.
5. Place door sprocket on door shaft and align with operator drive sprocket but do not insert keyway or set screws.
6. If an optional chain spreader has been ordered with your operator, install as shown below:




7. Install drive chain over sprockets, cut to a suitable length and connect with connecting link.
8. Lower or raise operator to adjust chain tension so that there is no more than 1/4" chain slack between sprockets. Tighten operator mounting bolts.
9. Carefully re-align sprockets, if necessary and secure keyway and set screws.


10. Install hand chain by wrapping it through chain guard holes and pocket wheel. Allow chain to hang down towards floor. Cut chain and connect so that chain is 2' to 3' from the floor.
11. Install chain keeper to wall near hand chain at approximately 4' from floor. Run disconnect chain through keyhole of chain keeper and cut excess chain links if required. Attach keyring to end of disconnect chain.



12. If an **optional** floor level disconnect lever was ordered in lieu of the chain keeper, mount to wall with suitable hardware. Attach both chains together using keyring provided. Allow disconnect chain to be slightly slack when lever is in the up position.



13. **IMPORTANT:** After installation is complete, remove red activation pin on reducer breather plug.



These are 3 possible electrical control configurations for this operator:

- A) **Standard relay logic controls (not UL325 (2010) compliant, not available in US).** Refer to electrical drawings inside your operator control box or generic drawings MS100-WW or MS300-WW in the electrical drawings section at the end of this manual.
- B) **Relay logic controls with Interface Module (UL325 (2010) compliant).** Refer to electrical drawings inside your operator control box or generic drawings MS100-IM- WW or MS300-IM-WW in the electrical drawings section at the end of this manual.
- C) **Full Feature logic board Smart 10.0 (UL325 (2010) compliant).** Refer to Section A for electrical Connections and logic board instructions. Refer to electrical drawings inside your operator control box or generic drawings MSL100-110V-WW, MSL300-WW, MSL300-WW or MSLC300-WW in the electrical drawings section at the end of this manual.

IMPORTANT

- EACH INDIVIDUAL COMMERCIAL DOOR OPERATOR MUST HAVE IT'S OWN DEDICATED POWER SUPPLY
- NICE HIGHLY RECOMMENDS THAT EACH INDIVIDUAL COMMERCIAL DOOR OPERATOR HAVE AN EXTERNAL CIRCUIT BREAKER OR FUSED DISCONNECT

⚠ WARNING ⚠

COMPARE AVAILABLE POWER SUPPLY VOLTAGE TO OPERATOR NAMEPLATE PRIOR TO ELECTRICAL CONNECTION. FAILURE TO CONNECT APPROPRIATE POWER SUPPLY VOLTAGE MAY CAUSE SERIOUS DAMAGE TO OPERATOR.

Refer to electrical diagrams inside control box cover or at the end of this manual prior to connection of power supply or control station.

⚠ WARNING ⚠

TO REDUCE THE RISK OF INJURY OR DEATH:

ALL ELECTRICAL CONNECTIONS SHOULD BE MADE BY A QUALIFIED SERVICE PERSON
DO NOT ATTEMPT TO MAKE ELECTRICAL CONNECTIONS TO OPERATOR UNLESS POWER SUPPLY HAS BEEN DISCONNECTED AT FUSE BOX.

OPERATOR MUST BE CONNECTED IN ACCORDANCE TO LOCAL ELECTRICAL CODES AND GROUNDED TO GREEN GROUND LUG LOCATED INSIDE CONTROL BOX.

SECTION A: PRO-GHV: PRO-GHCV Full Feature Logic Board Smart 10.0

[UL325 (2010) Compliant]


NOTE: The operator is shipped from the factory in the D1 mode setting (constant pressure open and close). The operator should remain in this mode until all connections and limit switch adjustments are completed.

Power Wiring Instructions

Connect primary power supply directly to the separate power terminal strip supplied using any of the 1-1/8" (2.85 cm) diameter holes provided on control box. Do not connect power supply directly to the circuit board.


Single Phase: Connect single-phase power supply to terminals L/L1 and N/L2 on three-pole power terminal strip (110V or 220V 1-phase).

Three-Phase: Connect three-phase power supply to terminals L1, L2 and L3 on three-pole power terminal strip (208V, 230V, 380V, 460V or 575V).



On Board O/C/S PBS Instructions

On-board Open, Close and Stop buttons are provided directly on the board for installation and troubleshooting purposes. In order to operate unit by on-board Open, Close, Stop buttons, the factory installed jumper (#1) between the COM and STOP terminals on the terminal strip must remain connected.




Motor Direction Verification

Make sure the mode of operation is selected to D1.

After electrical power connections are made, manually move door to mid-position. Using the on-board buttons press the "Open" button for several seconds and then press the "Stop" button. If door did not move in correct direction (or if limit cams not moving in correct direction towards the open limit switch) see below:


For Single-Phase Operators: The operators leave the factory with correct motor and limit shaft direction according to standard door installations. However, for special fire door, through wall mounting or other special door applications, the motor direction and limit switch direction may need to be reversed. A dipswitch (Dip #1) is provided to reverse direction of motor and limit switch direction. If motor direction is reversed, the open and close limit switches are automatically reversed. However, the advanced close limit switch needs to be manually changed. Disconnect the 2 wires from the advanced closed limit switch and re-connect to the auxiliary limit switch provided.

NOTE: Ensure that when the on-board open button is depressed and the door moves in the correct open direction that activation of the open limit switch illuminates the "OPEN LIMIT" LED and stops the door.



For 3-Phase Operators: If door moves in wrong direction, turn off incoming power and reverse any two of the three incoming power supply leads to correct rotation. Press the on board open button again. If door is going in the correct open direction, activate the open limit switch to ensure door stops. If door does not stop, turn off incoming power and interchange any two incoming power lines once again and slide dipswitch #1 to reverse motor direction. If motor direction is reversed, the open and close limit switches are automatically reversed. However, the advanced close limit switch needs to be manually changed. To do this, disconnect the 2 wires from the advanced limit switch and re-connect to the auxiliary limit switch provided.

NOTE: Ensure that when the on-board open button is depressed and the door moves in the correct open direction that activation of the open limit switch illuminates the "OPEN LIMIT" LED and stops the door.




Limit Switch Adjustments

Once the motor rotation and limit cam direction have been verified, adjust the limit cam settings. Please note that when each limit switch is activated the corresponding LED will light up. Refer to operator installation manual for complete limit switch adjustment instructions.

Connection of External O/C/S PBS

Connect O/C/S PBS as shown in diagram.

NOTE: Jumper #1 must be removed after the external O/C/S PBS has been installed.




Failsafe Feature

A safety device failsafe feature is built into the logic board. The logic board has provisions to connect one primary monitored safety device as well as 1 or more secondary non-monitored safety device(s).

Primary monitored safety device

Nice monitored failsafe photo beams or Nice compatible monitored failsafe devices must be connected to terminals P1 and P2 as primary monitored safety device. Primary monitored safety device must be connected if momentary activation on close is required in B2, T and TS modes. If it is not connected in B2, T and Ts modes, door can only be closed by constant pressure on close and if constant pressure is removed before door reaches full close position, door reverses to full open.

NOTE: Only one monitored failsafe device can be connected to terminals P1 and P2.



IMPORTANT!
NICE MONITORED SAFETY DEVICES MUST BE CONNECTED IF MOMENTARY ACTIVATION ON CLOSE IS REQUIRED.

Secondary Non-Monitored Safety Device(s):

A standard 2-wire safety edge, non-monitored photo beams or any other non-monitored reversing devices with a N.O contact can be connected to terminals S1 and S2 as secondary non-monitored safety device.

NOTE: More than one secondary non-monitored safety device can be connected to terminals S1 and S2.

IMPORTANT: Do not remove the resistor that is factory installed across terminals S1 and S2 unless installing a 4-wire electric edge.

4-wire electric edge:


A standard 4-wire electric edge can be connected across S1 and S2 terminals as a secondary safety device.

Remove the factory-installed resistor across terminals S1 and S2 when using a 4-wire electric edge.



Connection of External Single-Button Device

Connect an external single-button as shown in diagram. Please refer to “Modes of Operation” for the functionality of single-button.




Modes of Operation

All operators leave the factory in the D1 mode setting; please read all modes of operation and determine which operational mode is desired.


B2 (Momentary on open and close):

- **Open Button:** Momentary activation opens the door. When door is closing, momentary activation reverses the door (OPEN OVERRIDE). Momentary contact from mid-stop opens the door to full open position. Constant activation when door is opening, bypass mid-stop if enabled.
- **Close Button:** Momentary on close.
- **Stop Button:** Momentary activation stops the door.
- **Single Button Device and Single Channel Transmitter, 3-Channel (1,2,3) Transmitter:**
 - » **SEQUENTIAL FUNCTION:** Open/Stop/Close/Reverse.
 - » **COMMERCIAL FUNCTION:** Open/Close/Reverse.
- **3-Button O/C/S Radio Transmitter:** Same as open, close and stop buttons.
- **Safety Devices:** When door is closing, momentary activation reverses the door.
- **Timer to Close:** N/A




C2 (Momentary open, constant pressure close):

- **Open Button:** Momentary activation opens the door. When door is closing, momentary activation reverses the door (OPEN OVERRIDE). Momentary contact from mid-stop opens the door to full open position. Constant activation when door is opening, bypass mid-stop if enabled.
- **Close Button:** Constant pressure on close. Door will stop when button is released
- **Stop Button:** Momentary activation stops the door.
- **Single Button device:**
 - » **SEQUENTIAL FUNCTION:** Open/Stop/Constant pressure on close/stop.
 - » **COMMERCIAL FUNCTION:** Open/Constant pressure on close/stop.
- Single channel transmitter, 3-channel (1,2,3) transmitter and 3-button O/C/S radio transmitter. Momentary activation opens the door. Momentary contact of OPEN button on 3-button (O/C/S) radio transmitter from mid-stop opens the door to full open position. Cannot close the door.
- **Safety Devices:** When door is closing, momentary activation reverses the door.
- **Timer to Close:** N/A




D1 (Constant pressure on open and close):

- **Open Button:** Constant pressure opens the door. Door stops when constant pressure is released. Constant pressure from mid-stop opens the door to full open position.
- **Close Button:** Constant pressure on close. Door will stop when button is released
- **Single Button device, single channel transmitter, 3-channel (1,2,3) transmitter and 3-button (O/C/S) radio transmitter:** N/A
- **Safety Devices:** When door is closing, momentary activation reverses the door.
- **Timer to Close:** N/A




E2: (Momentary on open, constant pressure on close with roll-back feature)

- **Open Button:** Momentary activation opens the door. When door is closing, momentary activation reverses the door. Momentary contact from mid-stop opens the door to full open position. Constant activation when door is opening, bypass mid-stop if enabled.
- **Close Button:** Constant pressure on close. Door reverses to full open when button is released.
- **Single Button:**
 - » **SEQUENTIAL FUNCTION:** Open/Stop/Constant pressure on close/stop.
 - » **COMMERCIAL FUNCTION:** Open/Constant pressure on close/reverse.
- **Single channel device, 3-channel (1,2,3) transmitter and 3-button (O/C/S) radio transmitter:** Momentary activation opens the door. Momentary contact of OPEN button on 3-button (open/close/stop) radio transmitter from mid-stop opens the door to full open position. Cannot close the door.
- **Safety Devices:** When door is closing, momentary activation reverses the door.
- **Timer to Close:** N/A



T: (Momentary on open and close, timer to close, SAFETY ACTIVATION & STOP BUTTON DISABLE TIMER)



- **Open Button:** Momentary activation opens the door. When door is closing, momentary activation reverses the door. Momentary contact from mid-stop opens the door to full open position. Momentary contact at full-open refreshes the timer if enabled at full open. Momentary contact at full open position re-activates the timer if timer is disabled previously by stop button or safety device. Constant activation when door is opening, bypass mid-stop if enabled.
- **Close Button:** Momentary on close.
- **Single Button:** If door is opening or closing, momentary activation stops the door. Momentary activation while timer is counting at mid-stop or full open deactivates the timer.
- **Single button device, single channel and 3-channel (1,2,3) radio transmitter:**
 - » **SEQUENTIAL FUNCTION:** Open/Stop/Close/Reverse.
 - » **COMMERCIAL FUNCTION:** Open/Reverse/Refresh timer.
- **3-button (O/C/S) Transmitter:** Same as open, close, stop buttons.
- **Safety Devices:** When door is closing, momentary activation reverses the door to full open AND DISABLES TIMER.



- **Timer to Close:** Closes the door from mid-stop or full open. Momentary activation of stop button will deactivate the timer. When door is closing, momentary activation of safety devices will reverse the door to mid-stop (if enabled) or full open and deactivates the timer. Timer resumes its normal operation upon momentary activation of open push button or once the close cycle is completed. If mid-stop is enabled and “Timer from mid-stop only” dip-switch is ON, timer is enabled only from mid-stop and disabled from full open. If mid-stop is enabled and “Timer from mid-stop only” dip-switch is OFF, timer is enabled from full open and mid-stop.

TS: (Momentary on open and close, timer to close secure, STOP BUTTON DISABLES TIMER)

- **Open Button:** Momentary activation opens the door. When door is closing, momentary activation reverses the door. Momentary contact from mid-stop opens the door to full open position. Momentary contact at full open refreshes the timer if enabled at full open. Momentary contact at full open position re-activates the timer if timer has been disabled previously by stop button. Constant activation when door is opening, bypass mid-stop if enabled.
- **Close Button:** Momentary on close.
- **Stop Button:** If door is opening or closing, momentary activation stops the door. Momentary activation while timer is counting at mid-stop or full open deactivates the timer.
- **Single button device, single channel transmitter and 3-channel (1,2,3) radio transmitter:**
 - » **SEQUENTIAL FUNCTION:** Open/Stop/Close/Reverse.
 - » **COMMERCIAL FUNCTION:** Open/Reverse/Refresh timer.
- **3-button O/C/S radio transmitter:** Same as open, close, stop buttons.
- **Safety Devices:** When door is closing, momentary activation reverses the door. Momentary activation refreshes the timer to close.
- **Timer to Close:** Closes the door from mid-stop or full open. Momentary activation of stop button will deactivate the timer. Timer resumes its normal operation upon momentary activation of open push button or once the close cycle is completed. If mid-stop is enabled and “Timer from mid-stop only” dip-switch is ON, timer is enabled only from mid-stop and disabled from full open. If mid-stop is enabled and “Timer from mid-stop only” dip-switch is OFF, timer is enabled from full open and mid-stop.



WARNING: When replacing the logic board in a single-phase operator. Make sure that Jumper 2 is installed properly before operating the door. Failure to do this will damage the logic board.

Programming Instructions

NOTE: ALL PROGRAM FUNCTIONS CAN BE INITIATED BY TURNING SELECTOR SWITCH TO THE DESIRED SETTING AT ANY POINT DURING OPERATION EXCEPT FOR THE MID STOP and RUN TIMER MODE. PROGRAMMING MUST START FROM THE FULL CLOSED POSITION.

Run-Timer Setup

Run-timer is the maximum amount of time the motor will run upon receiving an open or close command. The factory default value for run-timer is 45 seconds.


NOTE: Limits must be set prior to setting run timer.

Modify the run-timer from factory default:

1. Close the door to full close position.
2. Set the selector dial to “Run-timer” position. The “Delay On Close Timer”. LED should blink.
3. Press open button. Wait until door reaches full open position. The run timer value is set to the time taken for the door to travel from full close position to full open position plus 5 seconds.
4. Set the selector dial to the desired mode of operation.

Modify the run-timer to factory default:

1. Close the door to full close position.
2. Set the selector dial to “Run-timer” position.
3. Press **Stop Button**. The run-timer is modified to the factory default value. Then set the selector dial to the desired mode of operation.



Mid-Stop Setup

Mid-Stop feature can be used to open the door to a preset point prior to full open position.

NOTE: Limits must be set prior to setting mid-stop position.

To Activate Mid-Stop:

1. Close the door to full close position.
2. Set the selector dial to “Mid-Stop” position. “Mid-Stop” LED starts blinking.
3. Press open push button. Door opens. Once the door reaches the desired mid-stop position, stop the door by activating stop push button.
4. Set the selector dial to the desired mode of operation.


NOTE: When door opens to the programmed mid-stop position, “Mid-Stop” LED will illuminate.

To Re-activate the Mid-Stop position:

1. Close the door to full close position.
2. Set the selector dial to “Mid-Stop” position.
3. Press the stop button, Mid-Stop is deactivated.

Modify mid-stop position:

To modify the current mid-stop position, follow the same steps to activate mid-stop. The new mid-stop position will override the old mid-stop position.





Timer to Close Setup

Timer to close is enabled only in TS and T modes of operation. To adjust the timer value turn POT1 clockwise to the desired value. The minimum value for timer to close is 3 seconds and the maximum value is 300 seconds.

Delay on Close Setup (only for use with optional apartment board)

Delay on close timer can be used to delay the closing of the door in B2 and TS modes of operation. This timer is deactivated in C2, D1, E2 and T modes of operation. Delay on close timer is OFF when the “Delay on close” dial is set to OFF position. To adjust this timer, rotate the dial clockwise to the desired value. The minimum value for delay on close timer is 1 second and the maximum value is 60 seconds. It is recommended to use this feature in apartment applications where RED and GREEN traffic lights are used.

NOTE: In TS mode, the “Delay on close” timer starts only once the “Timer to close” has finished counting. Unless a delay on close is required this dial should be rotated to the OFF position. If left in any other position but OFF, activation of close button will delay to POT2 amount of time.



On-Board Receiver Programming

This logic board has a built-in 372 MHz radio receiver and can only be used with Nice single button, 3-button (OPEN/CLOSE/STOP) and 3-channel radio transmitters.


Installing the Antenna

Direct Connection:

Attach the antenna when supplied with the operator to the F connector on the control box. For best reception, keep antenna wire straight and away from metal objects.

Indirect connection (Mounting the antenna at a remote location):

1. Connect coax extension cable (optional) to the F connector on the control box.
2. Route cable inside metal enclosure.
3. Route and secure cable away from moving parts.




4. Mount antenna holder (not provided) outside enclosure.
5. Attach antenna to extension wire.
6. Position antenna wire straight. For best reception, keep antenna away from metal.

NOTE: Do not route coax cable near any moving parts of the operator. If necessary, secure coax wire away from any moving parts.

Programming the On-Board Radio Receiver

WARNING: During programming, door operator will activate. Keep people and objects away from door.

1. Connect power to door operator.
2. Press and release the learn button once. The receiver's LED will turn on.
3. To program a single button transmitter, press the button on the transmitter. The receiver's LED will blink twice indicating a successful programming.
4. Press the button on the transmitter once more to confirm operation of the door operator.
5. To program a 3-channel (1,2,3) transmitter, press any of the 3 buttons on the transmitter. The receiver's LED will blink twice indicating a successful programming. Press the same button on the transmitter to confirm operation of the door operator. This button is now associated with that particular receiver. You can repeat the programming process for the other two buttons to control two other receivers.
6. To program a 3-button (O/C/S) transmitter, press OPEN button on the transmitter. The receiver's LED will blink twice indicating a successful programming. Press the OPEN button on the transmitter to confirm operation of the door operator. The OPEN, CLOSE and STOP buttons on the transmitter can be used to open, close or stop the operator respectively.
7. Test range of transmitter. Repositioning antenna may provide greater range.
8. Repeat transmitter-programming steps for additional transmitters.



Operation

1. Press and release the button on Nice transmitter.
2. Receiver LED will light momentarily and door will cycle.

To Erase all Learned Transmitters

1. Press and hold down the LEARN button.
2. After 5 seconds, the LED will blink for 5 seconds.
3. Release the LEARN button during the time LED is blinking.
4. After you released the button, the LED will blink 5 times indicating all transmitters are erased from the receiver's memory.

NOTE: A maximum of 20 transmitters can be programmed for the same receiver. If more than 20 are required, consult factory.

Replacing Remote Control Batteries

The batteries (lithium, 3V) should produce power for up to 5 years. To replace the battery, open the transmitter by removing the screws on the back of the transmitter. Match the positive and negative terminals of the battery to the positive and negative terminals of the transmitter.

NOTE: The receiver and transmitter comply with part 15 of the FCC rules with RSS-210 of industry Canada. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: If an external radio-receiver (Nice or other) is used instead of the built-in radio receiver, it is highly recommended to disconnect the co-axial cable from the logic board.

NOTE: When using any external receiver, the Nice on-board receiver should not be used.

Dip-Switch Setup

DIP-SWITCH	ON	OFF	NOTE
SEQ/COM	Single button and radio in SEQ mode	Single button and radio in COM mode	
Mid-stop Timer	Timer is enabled from mid-stop only	Timer is enabled from both mid-stop and full open	T or TS mode can be selected to enable a timer for mid-stop
Delay on reverse	Delay on reverse is 1.5 seconds	Delay on reverse is 0.5 seconds	Nice recommends 1.5 second delay on reverse for all applications
Motor direction	Reverse motor direction	Standard motor direction	See NOTE ** below

NOTE: If motor direction is reversed, the open and close limit switches are automatically reversed. However, the advanced close limit switch needs to be manually changed. To do this, disconnect the 2 wires from the advanced closed limit switch and re-connect to the auxiliary limit switch provided.

LED	Status	Cause
Fault	ON	<ul style="list-style-type: none"> » Primary safety devices not connected to P1 & P2 or not functioning properly » Safety devices are activated » 10k Ohm resistor (between S1 & S2) removed or faulty
Fault	Blinking	<ul style="list-style-type: none"> » Interlock is activated. » Interlock jumper is not connected
Run-out-timer	ON	Run-out timer has elapsed
Delay on close timer	Blinking	<ul style="list-style-type: none"> » Delay on close timer is counting » Selector dial is set to Run-timer
Timer to close	Blinking	Timer to close is counting.
Safety/Photo	ON	<ul style="list-style-type: none"> » Primary safety devices not connected to P1 & P2 or not functioning properly » Safety devices are activated » 10k Ohm resistor (between S1 & S2) removed or faulty
Mid. Stop	ON	Door is at Mid-stop position.
Close Limit	ON	Close limit switch is activated.
Open Limit	ON	Open limit switch is switched
Stop PB	ON OFF	<ul style="list-style-type: none"> » Stop button connected and functioning » Stop push button is activated (or the stop circuit is open).
Close Relay	Blinking	<ul style="list-style-type: none"> » Door is closing » Close relay is activated
Open Relay	Blinking	<ul style="list-style-type: none"> » Door is opening. » Open relay is activated.
Power	ON	24 VAC power to logic board is ON.

FAULT	
RUN-OUT TIMER	
DELAY ON CLOSE TIMER	
TIMER TO CLOSE	
SAFETY/PHOTO	
MID. STOP	
CLOSE LIMIT	
OPEN LIMIT	
STOP P.B.	
CLOSE RELAY	
OPEN RELAY	
POWER	

SECTION B: For all Operator Control Types

Limit Switch Adjustment

Adjustment of door travel is done by moving the limit cams on the threaded shaft. The position of the 4 limit switches are factory adjusted and should not be altered. The limit switches are:


- **“Open” limit switch:** End of door travel in the fully open position
- **“Closed” limit switch:** End of door travel in the fully closed position
- **“Advanced Open” or “Auxiliary advanced closed” limit switch:**
 - A) For relay logic operators this advanced open limit switch is used for open/close devices or timer to close features.
 - B) For logic board this auxiliary closed limit switch is used for open/close devices used when motor direction is reverse of standard.
- **“Advanced Closed” Limit switch:** Used to prevent reversing device from reversing door when door is almost fully closed.

⚠ WARNING ⚠

TO REDUCE THE RISK OF INJURY OR DEATH: DO NOT ATTEMPT TO MAKE LIMIT SWITCH ADJUSTMENTS UNLESS POWER HAS BEEN ELECTRICALLY DISCONNECTED.

To adjust door travel:

1. **Open cycle:** Depress cam plate and spin “Open” limit cam away from “Open” limit switch to increase door travel or spin “Open” limit cam towards the “Open” limit switch to decrease door travel. After each adjustment ensure that cam plate fully engages in slots of both limit nuts.
2. Adjust “Open” limit cam so that door stops at the desired fully open position.
3. **Close cycle:** Depress cam plate and spin “Close” limit cam away from “Close” limit switch to increase door travel or spin “Close” limit cam towards the “Close” limit switch to decrease door travel. After each adjustment ensure that cam plate fully engages in slots of both limit nuts.
4. Adjust “Close” limit cam so that door stops at the desired fully closed position.



SECTION C: For Operators with Interface Modules or Logic boards

Installation of Nice N-1 or N-4 Photocells

Installation Safety Precautions

⚠ WARNING ⚠

Nice MK00649 NEMA-1 and FRABA MK00697 NEMA 4/4X infrared photo systems are for use only with Nice logic board operators or relay logic operators equipped with the Nice failsafe interface module. Use of this device on other than recommended operators can lead to severe or fatal injury. Follow these instructions carefully.

IMPORTANT

For momentary activation on close, the Nice photobeams (or a Nice 2-wire monitored edge), must be installed as part of the operator system. If a Nice 2-wire monitored edge or the Nice infrared photobeam system is not installed (or not operating correctly), the operator will only operate in fault mode “constant pressure to close”.

READ and FOLLOW all installation instructions.

1. Before installing the photo beam, read the door or gate operator’s instruction manual fully, so you are aware of all of the unit’s functions and features.
2. Wear protective gloves and eye protection when using tools.
3. Before installing photo beam, disconnect all power to door operator to prevent unintended operation and have the door full open or close.
4. Do not reconnect power to the door or gate operator until instructed to do so.
5. Only install photobeams on a properly functioning door or gate operator.
6. Installation and wiring must comply with local building and electrical codes. This device is not intended and must not be installed in an explosive environment.

⚠ WARNING ⚠

Keep fingers and other body parts away from all moving parts of the door and gate operator system while the system is being operated.

⚠ WARNING ⚠

To prevent unintended operation, disconnect power to the door or gate operator prior to installing the photobeam system.

NICE N-1 Photocell (MK00649)


NOTE: The MK00649 photocell system has a maximum range of 24 ft. Sun visor protector optional.

Installation


NOTE: Photo beams should be mounted as close to the door track inside the door to offer maximum entrapment protection.

Wall installations


1. Select a location on the wall no more than 6 inches from the floor to install wall mounting brackets on the left and right side of the door. Both brackets must be mounted at the same height for proper alignment.
2. Drill holes in the wall and attach brackets to the wall using screws and nails provided as shown in Figure 1.



- Using the wing nuts, attach the receiver and transmitter of the photo system to the mounting brackets (with arrow pointing up). Note that the receiver and transmitter can be installed on the left side or right side of the door.
- Adjust the position of the transmitter and receiver on the slot of the brackets. Secure the receiver and transmitter to the mounting brackets as shown in Figure 2.



- Pair the two white wires and the two white/gray wires together from transmitter and receiver.
- Connect these paired wires to the P1 and P2 terminals on the logic board (or interface module if applicable) as shown in Figure 3.



NICE N-4 Photocell (MK00650)


NOTE: The MK00650 photocell system has a maximum range of 24 ft. Sun Visor protector optional.

Installation


NOTE: Photo beams should be mounted as close to the door track inside the door to offer maximum entrapment protection.

Wall installation


- Select a location on the wall no more than 6 inches from the floor to install wall mounting brackets on the left and right side of the door. Both brackets must be mounted at the same height for proper alignment.
- Drill holes in the wall and attach brackets to the wall using screws and nails provided as shown in Figure 1.



- Using the 8 Phillips head screws, attach the receiver and the transmitter to the two mounting plates (Figure 2A).
- Using the wing nuts, attach the receiver and the transmitter of the photo system to the mounting L-brackets (with arrow pointing up) as shown in Figure 2B. Note that the receiver and transmitter can be installed on the left or right side of the door. For applications requiring the photobeams to be further away from the wall, use the extension brackets provided as shown in Figure 2C.



- Adjust the position of the transmitter and receiver on the slot of the brackets and tightly secure the wing nuts.
- Loosen the 4 fastening screws and remove the cover from the photobeam transmitter and receiver housings and insert electrical wire through the strain relief (Figure 3A). Pair the two white/gray wires together from transmitter and receiver.
- Connect these paired wires to the P1 and P2 terminals on the logic board (or interface module if applicable) as shown in Figure 3B. Use minimum 18 gauge wires and secure the wires to wall or ceiling.



For Nice Nema-1 and Nema-4 photobeams

Aligning the photo beams:

- Turn the power on to the operator. If the transmitter and receiver are installed properly, the lights on both the transmitter (red LED) and receiver (green LED) will be ON.
- If the photo beams are not aligned properly, the receiver light (green) is OFF. Adjust the position of the transmitter and/or the receiver on the slot of the mounting bracket until the light on the receiver is ON and then secure to the bracket.

Photo system operation:

Nice photo beams must be connected for the door to close in momentary mode (unless a Nice monitored 2-wire edge is connected). When the photo system is properly installed and aligned, the infrared beam will detect any obstruction in the path of the beam. Upon detecting an obstruction, closing door will stop and reverse to full open.

The Nice operator control circuit continuously monitors the correct operation of the photo system. If the photo beams are not connected or not functioning properly, the operator will go into fail-safe mode and closing door will reverse to full open. In fail-safe mode door can only be closed by constant pressure on close.


To test the photo system:

- Open the door to full open position.
- Close the door.
- When door is closing, obstruct the beam. The door should stop and reverse.


FRABA N-4/4 Thru-Beam Photocell (MK00697)

NOTE: The MK00697 photocell system has a maximum range of 45 ft. Sun Visor protector optional.


1. Select a location on the wall no more than 6 inches from the floor to install wall mounting brackets on the left and right side of the door. Both brackets must be mounted at the same height for proper alignment.
2. Drill holes in the wall and attach brackets to the wall using screws provided as shown in Figure 4.





3. Plug sensors into flexible adapters as shown in Figure 5. Please note that the 2 brackets are not identical. The receiver (Rx) must be installed into the receiver adapter and the transmitter (Tx) must be installed into the transmitter adapter (Figure 6).



4. Pair the two black and the two black with white tracer wires together from transmitter and receiver. Connect these paired wires to the P1 and P2 terminals on the logic board (or interface module if applicable) as shown in Figure 7. Use minimum 18 gauge wires and secure the wires to wall or ceiling.



5. Turn the power on to the operator. Align transmitter and receiver by adjusting angle and height of the fixture (Figures 8A and 8B).



6. Utilize LEDs on photocells for alignment and trouble shooting. Make sure to tighten screws and wing nuts after photocells are aligned.
 - **Red LED (ON), Green LED (ON):** Normal operation
 - **Red LED (ON), Green LED (OFF):** No power. Verify wiring
 - **Red LED (Blinking twice), Green LED (ON):** Bad Alignment, or Obstructed Beam, or Rx defective
 - **Red LED (Blinking twice), Green LED (OFF):** Check power and wiring to Rx, or Rx defective
 - **Red LED (Blinking three times), Green LED (ON):** Rx receiving sunlight (or interference). Install visor or interchange position of transmitter and receiver to reduce sunlight affecting receiver.

To test the photo system: Open the door to full open position. Close the door. When door is closing, obstruct the beam. The door should stop and reverse.

Clutch Adjustment



In-Line Clutch

If an optional In-line Clutch was ordered with your operator:

1. Loosen bolts on clutch cover and slide cover towards motor to access clutch.
2. Loosen the two set screws on clutch adjustment nut.
3. Rotate clutch nut counterclockwise (loosen) until there is insufficient tension to permit clutch to drive door.

NOTE: When adjusting Nut, make sure to secure input shaft to not allow shaft to rotate when tightening or loosening nut.

4. Gradually tighten clutch nut until the tension is sufficient to permit clutch to drive door smoothly but will allow clutch to slip if door is obstructed. It should be possible to stop moving door by hand if clutch is properly adjusted.
5. Tighten the 2 set screws after each time the unit is tested for clutch adjustment. After adjustment is completed make sure set screws are locked in place. Re-install clutch cover.



Fire Release Mechanism Installation

If an optional Fire Release Mechanism was ordered with your operator:

1. Loosen socket head cap screw on adjustment nut. Loosen the fire release adjustment nut.
2. Slide fire release assembly onto output shaft of reducer. Align assembly so that the drive sprocket on assembly is aligned with door sprocket when the assembly is not engaged (i.e. when the engagement arm is at rest and the internal spring is not compressed).
3. Tighten set screw on fire release hub.
4. Using fire release adjustment tool, rotate fire release adjustment nut so as to allow 3/16" clearance between the clutch hub and the drive sprocket hub when the mechanism is not engaged.
5. After adjustment is completed make sure socket head cap screw on clutch nut is locked in place.
6. Verify fire release mechanism by pushing or pulling the engagement arm so as to engage the 3 ball bearings into the 3 holes in the drive sprocket.
7. Rotate and position engagement arm so as to not interfere with operator drive chain. Slide stabilizing rod through slot of engagement arm and attach to frame or external support to prevent arm from rotating during operation.


NOTE: Location of arm and stabilizing bolt vary depending on mounting and specifics of the particular installation.

8. Attach fusible link (not supplied) to cable tensioner on cable assembly. Using pulleys and sash chain provided, position cable assembly so as to locate fusible link in appropriate location to suit installation.

NOTE: Cable assembly may be installed to pull release arm towards the operator or away from operator, whichever is most applicable to the particular installation.

9. Attach the keyring located at the end of sash chain to a fixed location so that tension on cable will cause engagement arm to fully engage the fire release mechanism.
10. When fusible link melts, the cable should release tension on the arm allowing the spring loaded fire release mechanism to disengage drive sprocket causing an open door to close under it's own weight.

NOTE: Limit switch settings must be re-adjusted anytime the fire release has been activated.




Brake Adjustment

The brake adjustment is factory set and should only require minor adjustment after extensive use.

Verify brake adjustment by manually holding in solenoid plunger. When brake is properly adjusted, the brake shoe pads should make complete contact with brake drum with sufficient brake spring tension to stop and maintain door when solenoid is de-energized. When solenoid is energized, brake shoes should release from drum with sufficient clearance to avoid contact between shoes and drum.

To adjust brake tension, tighten (to increase) or loosen (to decrease) nylon lock nut on brake spring bolt. Observe solenoid during electrical testing of brake. Brake spring tension must be adjusted so that solenoid should pull and release smoothly and quietly. Too much or too little tension on brake spring may cause solenoid to burn out.

To adjust individual brake shoes, loosen nut on brake shoe adjustment bolt and adjust bolt. When properly adjusted, there should be a small clearance between adjustment bolt and solenoid bracket when solenoid is de-energized. When solenoid is energized, brake shoes should move away from drum with sufficient clearance to avoid friction between brake shoe pad and drum. After adjustments are made be sure to tighten nuts on brake shoe adjustment bolts.



Emergency Manual Operation

- The PRO-GH and PRO-GHC operators are equipped with an emergency disconnect device with interlocked power cut-out switch to manually operate door in case of emergency. This feature should not be used to manually operate a malfunctioning door.


⚠ WARNING ⚠

TO REDUCE THE RISK OF INJURY OR DEATH:

DO NOT ATTEMPT TO USE EMERGENCY DISCONNECT SYSTEM WHILE OPERATOR IS RUNNING.

POWER TO THE OPERATOR SHOULD BE TURNED OFF PRIOR TO OPERATING MANUALLY.



1. **If operator is supplied with standard chain keeper:** Pull the disconnect chain through the hole of keyhole and lock in place by inserting chain in slot of keyhole.



2. **If operator is supplied with optional floor level disconnect lever:** Pull disconnect lever downwards and lock in place by bending lever around bracket lip as shown.



3. Operate door by pulling on hand chain. To return to electrical operation, release disconnect chain and allow to return to original position. Lock hand chain in place (to Chain Keeper or Floor Level Disconnect) when not in use.




WARNING

TO REDUCE THE RISK OF INJURY OR DEATH:

DO NOT ATTEMPT TO SERVICE THE OPERATOR UNLESS POWER SUPPLY HAS BEEN DISCONNECTED.

- Inspect manual function of the door every 3 months. Make sure that door runs smoothly. If door does not manually open or close freely, have a qualified service person make repairs. Do not attempt to electrically operate a malfunctioning door.
- **Every 3 months:**
 1. Verify that door area is kept clean. Remove any obstructions that would prevent proper door operation.
 2. Check for any excessive slack in chains. If chain adjustment is required verify and adjust limit switches, if necessary.
 3. Verify and adjust brake (Do not lubricate).
 4. Lubricate chains, bearings and limit shaft.
 5. Verify that motor, solenoid and operator runs smoothly and quietly.
- **Every 6 months:**
 1. Verify tightness of all fasteners and set screws.
 2. Verify that operator is properly secured.
 3. Inspect manual disconnect.
- **Every 12 months:**
 1. Perform a complete service check.
 2. Verify that inside of control box is clean and that grounding wires, terminations and power terminations do not show signs of corrosion.
 3. Verify tightness of all terminal strip screws and electrical connections.
 4. Verify power supply, voltage of input terminals during operation.
 5. Verify that current consumption of operator corresponds to nameplate information.

Jackshaft Operator Pro-GH Parts Diagram




Jackshaft Operator Pro-GH Parts List

CODE	ITEM #	DESCRIPTION (PRO-GH)	QUANTITY
MB01003	1	Motor 1/2HP 110/230V 1PH TEFC 56C	1
MC00001	2	Gear Reducer Chenta 55 45:1 56C	1
MD00001	3	Bevel Gear 20 Teeth - 3/4" ID	1
MD00002	4	Bevel Gear 20 Teeth - 5/8" ID	1
MD00005	5	410B12 x 3/8" Sprocket	1
MD00025	6	Sprocket 410B23 x 1"	1
MD00225	7	#410 Roller Chain 67 Links C/W Connecting Link (For Reducer CH 55)	1
MD00409	8	Thrust Needle Bearing NTA 1220	1
MD00410	9	Thrust Washer 3/4" ID	2
ME00001	10	Limit Shaft 3/8" - 1/2" x 9.75"	1
ME00008	11	Disconnect Shaft Gearhead 3/4" x 15.75"	1
MF00003	12	R.H. Philips Machine Screw 4-40 UNC x 1-1/2"	8
MF00004	13	R.H. Philips Machine Screw 6-32 UNC x 1"	2
MF00005	14	R.H. Philips Machine Screw 10-32UNF x 5/8"	2
MF00008	15	Hex Head Bolt 1/4"-20UNC x 1"	1
MF00009	16	Hex Head Bolt 1/4" - 20UNC x 2-1/4" (Partial Thread)	2
MF00019	17	Hex Head Bolt 3/8-16UNC x 1"	2
MF00020	18	Hex Head Bolt 3/8-16UNC x 1-1/4"	2
MF00032	19	Hex Head Slotted Bolt 5/16"-18UNC x 3/4"	4
MF00045	20	Hex Head Slotted Self Rounding Washer Head Screw 8-32UNF x 3/8"	10
MF00046	21	Hex Head Slotted Self Rounding Washer Head Screw 10-32UNF x 1/2"	4
MF00124	22	HHB Ser Wash Type F Head Reg Thr #10-32 x 1/2"	1
MG00003	23	Double Nut for Lim-Sw	4
MG00006	24	Hex Nut 1/4-20UNC	1
MG00007	25	Hex Nylon Lock Nut 6-32UNC	2
MG00008	26	Hex Nylon Lock Nut 10-32UNF	2
MG00009	27	Hex Nylon Lock Nut 1/4"-20UNC	1
MG00010	28	Ribbed Hex Nut 10-32UNF	4
MG00011	29	Ribbed Hex Nut 1/4" - 20	4
MG00016	30	Flat Washer #10	3
MG00017	31	Flat Washer 0.25 ID x 0.5" OD	2
MG00018	34	Lock Washer for 3/8" Screw	4
MG00030	33	Limit Cam 1/2"-20UNF	2
MG00042	34	Lock Washer 5/16"	4
MG00099	35	Flat Washer 13/16" ID x 1.5" OD x 1/16" Thick	1
MH00001	36	T-Bushing 3/8" ID	2
MH00003	37	Bronze Flange Bushing 3/4" ID x 7/8" OD	2
MH00006	38	Collar 3/8" ID - 3/4" OD	1
MH00008	39	Collar 3/4" ID - 1.25" OD	4
MH00110	40	Bronze Flange T-Bushing 0.752 ID x 1.00 OD x 0.50 Long	1
MI00003	41	Pocket Wheel C/W 2 Pins and Bushing 3/4" ID	1
MJ00006	42	Limit Switch Double Spacer 3/4"	4
MJ00014	43	Brake Assembly #2 (Gearhead Operator 3")	1
MK00004	44	Limit Switch	4
MK00026	45	Solenoid 120V	1
MK00027	45	Solenoid 240V	1
MK00028	45	Solenoid 460V	1
MK00029	45	Solenoid 575V	1

Jackshaft Operator Pro-GH Parts List

CODE	ITEM #	DESCRIPTION (PRO-GH)	QUANTITY
MM00001	46	Control Box Cover	1
MM00002	47	Control Box MSI0001	1
MM00004	48	Frame Gearhead MSI0030	1
MM00005	49	Gearhead Back Cover	1
MM00015	50	Solenoid Lever Gearhead Operator	1
MM00017	51	Pivot Bracket Gearhead	1
MM00020	52	Disconnect Arm Gearhead	1
MM00024	53	Cam Plate	1
MM00026	54	Cut-Out Switch Activation Plate GH	1
MM00027	55	Rear Box Support Bracket GH	1
MM00046	56	Control Box Hinge	2
MM00431	57	Chain Guard	1
MO00001	58	Cam Plate Compression Spring (0.178ID x 0.032G x 0.55L)	2
MO00006	59	Spring #5 0.92"ID x 0.09" x 2.00" LB E.G. #5	1
MQ00001	60	Cotter Pin 1/8 x 1.5"	1
MQ00007	61	Spring Pin 1/4" x 2"	2
MQ00008	62	Set Screw 5/16"-18UNC	12
MQ00009	63	Set Screw 1/4" - 20	3
MQ00011	64	3/32" Aluminum Oval Sleeves	1
MQ00018	65	Cotter Pin 3/16 x 2"	1
MR00001	66	3/32" Cable 13" Long C/W Cable Stop	1
MR00006	67	Hand Chain Door Height	1
MR00008	68	Disconnect Sash Chain	1
MU00001	69	Swivel Pulley	1
MU00002	70	Keyring 1-1/4"	1

Jackshaft Operator Pro-GHC Parts Diagram




Jackshaft Operator Pro-GHC Parts List

CODE	ITEM #	DESCRIPTION (PRO-GHC)	QUANTITY
MB01003	1	Motor 1/2HP 110-230V 1PH TEFC 56C	1
MC00012	2	Gear Reducer BHC 63 40:1 (For 1/2, 3/4, 1 and 1.5HP)	1
MC00007	2	Gear Reducer BHC 80 40:1 143TC (For 2HP)	1
MC00008	2	Gear Reducer BHC 80 40:1 182TC (For 3 and 5HP)	1
MD00001	3	Bevel Gear 20 Teeth - 3/4" ID	1
MD00002	4	Bevel Gear 20 Teeth - 5/8" ID	1
MD00005	5	410B12 x 3/8" Sprocket	1
MD00008	6	#410 Chain (49 Links C/W Link)	1
MD00051	7	Sprocket 410B23 x 1-1/4" (For 1/2, 3/4, 1 and 1.5HP)	1
MD00052	7	Sprocket 410B32 x 1-3/8" (For 2, 3 and 5HP)	1
MD00409	8	Thrust Needle Bearing NTA 1220	1
MD00410	9	Thrust Washer 3/4" ID	2
ME00001	10	Limit Shaft 3/8" - 1/2" x 9.75"	1
ME00008	11	Disconnect Shaft Gearhead 3/4" x 15.75"	1
MF00002	12	Hex Head Bolt 1/2"-13UNC x 1-1/4" (Full Thread)	4
MF00003	13	R.H. Philips Machine Screw 4-40 UNC x 1-1/2"	8
MF00004	14	R.H. Philips Machine Screw 6-32 UNC x 1"	2
MF00005	15	R.H. Philips Machine Screw 10-32UNF x 5/8"	2
MF00006	16	Hex Head Bolt 1/4"-20UNC x 1/2"	2
MF00007	17	Hex Head Bolt 1/4"-20UNC x 3/4"	4
MF00008	18	Hex Head Bolt 1/4"-20UNC x 1"	1
MF00009	19	Hex Head Bolt 1/4"-20UNC x 2-1/4" (Partial Thread)	2
MF00011	20	Hex Head Bolt 3/8"-16UNC x 3/4" Long	10
MF00019	21	Hex Head Bolt 3/8-16UNC x 1"	6
MF00020	22	Hex Head Bolt 3/8-16UNC x 1-1/4"	2
MF00045	23	Hex Head Slotted Self Rounding Washer Head Screw 8-32UNF x 3/8"	10
MF00046	24	Hex Head Slotted Self Rounding Washer Head Screw 10-32UNF x 1/2"	4
MF00124	25	HHB Ser Wash Type F Head Reg Thr #10-32 x 1/2"	1
MG00001	26	Ribbed Hex Nut 1/2"-13UNC	4
MG00003	27	Double Nut for Lim-Sw	4
MG00006	28	Hex Nut 1/4-20UNC	1
MG00007	29	Hex Nylon Lock Nut 6-32UNC	2
MG00008	30	Hex Nylon Lock Nut 10-32UNF	2
MG00009	31	Hex Nylon Lock Nut 1/4"-20UNC	1
MG00010	32	Ribbed Hex Nut 10-32UNF	4
MG00011	33	Ribbed Hex Nut 1/4"-20	10
MG00013	34	Ribbed Hex Nut 3/8"-16 UNC	8
MG00016	35	Flat Washer #10	3
MG00017	36	Flat Washer 0.25 ID x 0.5" OD	2
MG00018	37	Lock Washer for 3/8" Screw	10
MG00030	38	Limit Cam 1/2"-20UNF	2
MG00099	39	Flat Washer 13/16" ID x 1.5" OD x 1/16" Thick	1
MH00001	40	T-Bushing 3/8" ID	2
MH00003	41	Bronze Flange Bushing 3/4" ID x 7/8" OD	2
MH00004	42	Flange Bearing C.I. 1-1/4" UCFL 207 20G Pillow Block (For 2 and 3HP)	2
MH00005	42	Flange Bearing C.I. 1-1/4" UCFL 207 20G Pillow Block (For 1/2, 3/4, 1 and 1.5HP)	2
MH00006	43	Collar 3/8" ID - 3/4" OD	1
MH00008	44	Collar 3/4" ID - 1.25" OD	4
MH00110	45	Bronze Flange T-Bushing 0.752 ID x 1.00 OD x 0.50 Long	1
MI00003	46	Pocket Wheel C/W 2 Pins and Bushing 3/4" ID	1
MJ00006	47	Limit Switch Double Spacer 3/4"	4
MJ00014	48	Brake Assembly #2 (Gearhead Operator 3")	1

Jackshaft Operator Pro-GHC Parts List

CODE	ITEM #	DESCRIPTION (PRO-GHC)	QUANTITY
MK00004	49	Limit Switch	4
MK00026	50	Solenoid 120V	1
MK00027	50	Solenoid 240V	1
MK00028	50	Solenoid 460V	1
MK00029	50	Solenoid 575V	1
MM00001	51	Control Box Cover	1
MM00002	52	Control Box MSI0001	1
MM00004	53	Frame Gearhead MSI0030 (For 1/2, 3/4, 1, 1.5, 2HP)	1
MM00255	53	Frame GH 3HP (For 3HP)	1
MM00005	54	Gearhead Back Cover	1
MM00008	55	Frame Gearhead Canadian MSI0034	1
MM00015	56	Solenoid Lever Gearhead Operator	1
MM00017	57	Pivot Bracket Gearhead	1
MM00020	58	Disconnect Arm Gearhead	1
MM00024	59	Cam Plate	1
MM00026	60	Cut-Out Switch Activation Plate GH	1
MM00027	61	Rear Box Support Bracket GH (For 1/2, 3/4, 1 and 1.5HP)	1
MM00028	61	Rear Bracket GHC (RED 80-182TC) (For 2 and 3HP)	1
MM00029	62	Reducer Support Bracket Gearhead (For 1/2, 3/4, 1 and 1.5HP)	1
MM00030	62	Frame/Reducer 80 Support Bracket (For 2 and 3HP)	1
MM00046	63	Control Box Hinge	2
MM00149	64	Frame Support U-Bracket Gearhead Pro-GHC	2
MM00431	65	Chain Guard	1
MO00001	66	Cam Plate Compression Spring (0.178ID x 0.032G x 0.55L)	2
MO00006	67	Spring #5 0.92"ID x 0.09" x 2.00" LB E.G. #5	1
MQ00001	68	Cotter Pin 1/8" x 1.5"	1
MQ00007	69	Spring Pin 1/4" x 2"	2
MQ00008	70	Set Screw 5/16"-18UNC	12
MQ00009	71	Set Screw 1/4"-20	3
MQ00011	72	3/32" Aluminum Oval Sleeves	1
MQ00018	73	Cotter Pin 3/16 x 2"	1
MR00001	74	3/32" Cable 13" Long C/W Cable Stop	1
MR00006	75	Hand Chain Door Height	1
MR00008	76	Disconnect Sash Chain	1
MU00001	77	Swivel Pulley	1
MU00002	78	Keyring 1-1/4"	1

MS100-WW-F 1-Phase Wiring Diagram




MOTORS
230 VAC
3PH, 60HZ
--HP


VARIABLE
FREQUENCY
DRIVE

TO REVERSE MOTOR
ROTATION, INTER-CHANGE
TERMINALS U AND V

Checked By: OUSSAMA	Sheet: 1 / 1
Check date:	Rev.: B
Description:	1-PHASE WIRING SCHEMATIC
Drawn By:	
Drawing date: 06.02.20	
Nice	
Nice Group Canada Inc. 1380 St Regis Blvd, Dorval, QC H9P 2T5	
This drawing is strictly confidential and reserved by law. The total or partial reproduction without authorization is prohibited/interdiction.	
Project Number:	MSL100-VFD-S



MS100-IM-WW-F 1-Phase Wiring Diagram



IF STOP BUTTON USED, REMOVE "STOP" AND "COM" TERMINALS.

MONITORED PHOTO EYE OR NICE COMPATIBLE CONNECTED TO P1 AND P2 FOR THE DOOR TO BE OPENED. MODE (B3 OR T5). IF MONITORED SAFETY CONNECTED, DOOR CAN ONLY BE CLOSED BY PRESSING STOP AND IF CONSTANT WIRE REMOVED REACHES FULL CLOSE POSITION. MONITORED DEVICE CAN BE CONNECTED TO P2 AND P1.

ONE OR MORE SECONDARY SAFETY DEVICES CAN BE CONNECTED TO S1 AND S2.


DO NOT REMOVE SAFETY DEVICES. INSTALLING ON A 4-WIRE ELECTRIC CODE.

REFER TO INSTALLATION MANUAL FOR APPROPRIATE PROTECTOR RATINGS.

OPERATOR IS FACTORY CONSTANT PRESSURE TO CLOSE. GOTO MODE OF MOMENTARY ON CLOSE JUMPER FROM PIN "C2" AND PLACE IT TO CLOSE. IF TIMER REQUIRED, PLACE THE JUMPER ON PINS "C1".

TIMER TO CLOSE. REFER TO THE DEFAULT SETTING OF TIMER. TO CLOSE IS 3 VALUE. PRESS "TIMER" PROGRAM BUTTON. VALUE IS REACHED. REFER TO ON BOARD LED INDEX INDICATION.

Checked By: DUSSAMA	Sheet: 1 / 1
Check date: 18.09.19	Rev.: E
Description: Nice	3-PHASE WIRING SCHEMATIC
Project number: MSL300-VFD-S Drawing ID: NICE GROUP CANADA INC. 1380 St Regis Blvd, Dorval, QC H9P 2T5 This drawing is strictly confidential and reserved by law. The total or partial reproduction without authorization is prohibited/forbidden.	



Notes

Lined writing area

Technical Support:
877-888-1116

Technical Support Hours:
M – F, 8:00 a.m. – 6:00 p.m. ET

Nice North America
c/o Customer Service
5919 Sea Otter Place, Suite 100
Carlsbad, CA 92010



Niceforyou.com

©2024 Nice North America LLC.
All rights reserved.